


Current part is item (3) on diagram. Available at www.oshkosequipment.com

| (1) (a) FIG. NO. | (2) (b) ITEM NO. | (3) SMR CODE | (4) NATIONAL STOCK NUMBER | (5) (6) PART NUMBER | (6) FSCM | (7) DESCRIPTION U/M | (8) INC IN UNIT |
|------------------------------------|---------------------------|--------------------|------------------------------------|------------------------------|-------------|---|--------------------------|
| 0601-GENERATOR,ALTERNATOR (CONT'D) | | | | | | | |
| 55 | 2 | PAOZZ | 5305-00-042-3571 | 423571 | 21450 | SCREW,ASSEMBLED WASHER: ADJUSTING ARM AA | EA 2 |
| 55 | 3 | PAOZZ | 5310-00-080-6004 | MS27183-14 | 96906 | WASHER,FLAT: ADJUSTING ARM BOLT AA | EA 1 |
| 55 | 4 | PAOZZ | 2920-00-605-1403 | 7539524 | 19207 | ARM,ADJUSTING GENERATOR: BELT TENSION AA | EA 1 |
| 55 | 5 | PAOFF | 2920-00-293-4380 | 7355736 | 19207 | GENERATOR,ENGINE ACCESSORY AA | EA 1 |
| 55 | 5 | PAOFF | 2920-00-903-9534 | 10950808 | 19207 | GENERATOR,ENGINE ACCESSORY AA | EA 1 |
| 55 | 6 | PAOZZ | 5305-00-710-4194 | MS90726-89 | 96906 | SCREW,CAP,HEXAGON HEAD: GENERATOR BRACKET AA | EA 1 |
| 55 | 7 | XBOZZ | | 7971422 | 19207 | BRACKET,GENERATOR: MOUNTING AA | EA 1 |
| 55 | 8 | PAOZZ | 5310-00-088-0552 | MS21044N7 | 96906 | NUT,SELF-LOCKING: BRACKET SCREW AA | EA 2 |
| 55 | 9 | PAOZZ | 5305-00-317-3102 | 594119 | 21450 | SCREW,ASSEMBLED WASHER: BRACKET TO BLOCK AA | EA 4 |
| 55 | 10 | PAOZZ | 5305-00-710-4195 | MS90726-90 | 96906 | SCREW,CAP,HEXAGON HEAD: GENERATOR BRACKET AA | EA 1 |
| 55 | 11 | PAOZZ | 5315-00-616-5526 | MS35756-8 | 96906 | KEY,WOODRUFF: ARMATURE SHAFT AA | EA 1 |
| 55 | 12 | PAOZZ | 5315-00-816-1794 | MS24665-285 | 96906 | PIN,COTTER: GROOVE PULLEY NUT AA | EA 1 |
| 55 | 13 | PAOZZ | 5310-00-842-1490 | MS35692-37 | 96906 | NUT,PLAIN,BLIND RIVET: GROOVE PULLEY AA | EA 1 |
| 55 | 13 | PAOZZ | 5310-00-902-9369 | MS21083N8 | 96906 | NUT,SELF-LOCKING: GROOVE PULLEY AA | EA 1 |
| 55 | 14 | PAOZZ | 5310-00-809-5998 | MS27183-18 | 96906 | WASHER,FLAT: GROOVE PULLEY NUT AA | EA 1 |
| 55 | 14 | PAOZZ | 5310-00-584-5272 | MS35338-48 | 96906 | WASHER,LOCK: GROOVE PULLEY NUT AA | EA 1 |
| 56 | 1 | PAOZZ | 5310-00-407-9566 | MS35338-45 | 96906 | WASHER,LOCK: NEGATIVE CABLE TO ALTERNATOR | EA 1 |
| 56 | 2 | PAOZZ | 5306-00-225-8494 | MS90725-29 | 96906 | BOLT,MACHINE: NEGATIVE CABLE TO ALTERNATOR | EA 1 |
| 56 | 3 | PAOFF | 2920-00-909-2483 | 10929868 | 19207 | ALTERNATOR,ENGINE: RECTIFIED GENERATING SYSTEM 60 AMPERE | EA 1 |
| 56 | 4 | PAOZZ | 5315-00-616-5526 | MS35756-8 | 96906 | KEY,WOODRUFF: ALTERNATOR SHAFT | EA 1 |
| 56 | 5 | PAOZZ | 5305-00-269-3210 | MS90725-59 | 96906 | SCREW,CAP,HEXAGON HEAD: ALTERNATOR TO STRAP ADJUSTING ARM | EA 1 |
| 56 | 6 | PAOZZ | 5310-00-959-4675 | MS35340-46 | 96906 | WASHER,LOCK: ALTERNATOR TO STRAP ADJUSTING ARM, STRAP ADJUSTING ARM TO ENGINE | EA 2 |
| 56 | 7 | PAOZZ | 5310-00-143-6488 | 10871194 | 19207 | WASHER,KEY: ALTERNATOR TO STRAP ADJUSTING ARM | EA 1 |
| 56 | 8 | PAOZZ | 2920-00-071-8857 | 11647748 | 19207 | BRACKET: ADJUSTING ARM TO ENGINE | EA 1 |
| 56 | 9 | PAOZZ | 5310-00-732-0558 | MS51967-8 | 96906 | NUT,PLAIN,HEXAGON: STRAP ADJUSTING ARM TO ENGINE | EA 1 |



Current part is item (3) on diagram. Available at www.oshkosequipment.com



TA 031526

Figure 56. 60 ampere alternator.