



FIGURE 40. TURN SIGNAL.

TA215410

Current part is item (1) on diagram. Available at www.oshkoshequipment.com

SECTION II (1)	(2)	(3)	(4)	(5)	(6)
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON CODE (UOC)	QTY
				GROUP:0607 INSTRUMENT OR CONTROL PANEL	
				FIGURE 40. TURN SIGNAL.	
1	PAOZZ	03533	A-105A-5	FLASHER, THERMAL	1
2	PAOOO	77977	900	CONTROL, DIRECTIONAL	1
3	PBOZZ	77977	7-107-70	.HANDLE, MANUAL CONTR	1
4	PBOZZ	24617	9415346	.SCREW	2
5	PBOZZ	77977	00-00111-00000	.LENS, LIGHT	1
6	PAOZZ	81348	W-L-00111/61	.LAMP, INCANDESCENT	1
7	PBOZZ	77977	19-254	.STRAP, RETAINING	1
8	PAOZZ	21793	600429	SWITCH, TOGGLE	1
9	PAOZZ	24617	9419912	NUT, PLAIN, HEXAGON	2
10	PAOZZ	96906	MS35338-48	WASHER, LOCK	2
11	PAOZZ	80089	14603-3	SWITCH, FOOT, DIMMER	1
12	PAOZZ	24617	191985	SCREW, ASSEMBLED	2
13	PAOZZ	24617	160539	SCREW	2
14	PAOZZ	24617	9422037	SCREW, TAPPING, THREA	4
15	PAOOO	34623	MD32-20072	BRACKET, FOOT SWITCH	1
16	PAOOO	34623	MB70-20111	.PEDAL, CONTROL	1
17	PAOOO	34623	MA207-200089	.PEDAL, PAD	1
18	PAOZZ	75078	007007	WIRING HARNESS	1
19	PAOZZ	75078	007006	SWITCH, FOOT	1

END OF FIGURE



Current part is item (1) on diagram. Available at www.oshkoshequipment.com