

| (1) SMR Code | (2) Federal Stock Number | (3) Description | (4) Unit of Meas. | (5) Qty | (6) 15-day Maintenance In Unit | (7) Organizational alw Illustration | (a) Figure No. | (b) Item No. |
|---|-----------------------------------|---|----------------------------|------------|--|--|----------------------|--------------------|
| Reference number & mfg. code | | | | | | | | |
| Usable on code | | | | | | | | |
| 0610-SENDING UNITS AND WARNING SWITCHES-CONTINUED | | | | | | | | |
| PAOZZ | 2910-753-9072 | GASKET:FUEL TANK TRANSMITTER (1 USED ON M39,M40,M41, M54,M55,M63,M139,M139C,M139D,M246) 7539072 (19207) | DA,DB,EA, HA,BD | EA | 2 | * * * * | 78 | 4 |
| PAOZZ | 4730-188-1854 | NIPPLE:1/4 X 1-1/2 SHORT,OIL PRESSURE TRANSMITTER TEE PIPE TO CRANKCASE 105407 (21450) | AA | EA | 1 | * * * * | 79 | 1 |
| PAOZZ | 4730-202-6491 | BUSHING:3/8 NPT X 1/4 NPT 119928 (21450) | AA | EA | 1 | * * * * | 79 | 1 |
| PAOZZ | 6620-814-4770 | TRANSMITTER,PRESSURE:OIL GAGE 60 PSI USED W/INDICATOR,FSN 6620-056-9584 MS24538-1 (96906) | AA | EA | 1 | * * * * | 79 | 2 |
| PAOZZ | 4730-249-2029 | TEE,PIPE:OIL GAUGE TRANSMITTER WWP521 (81348) | AA | EA | 1 | * * * * | 79 | 3 |
| PAOZZ | 4730-288-8572 | PLUG:OIL PRESSURE TRANSMITTER TO NIPPLE TEE PIPE WWP471TYPE1 (81348) | AA | EA | 1 | * * * * | 79 | 4 |
| PAOZZ | 6685-814-5271 | TRANSMITTER,TEMPERATURE:WATER MS24537-1 (96906) | AA | EA | 1 | * * * * | 79 | 5 |
| PAOZZ | 6620-814-4770 | TRANSMITTER,PRESSURE:OIL PRESSURE MS24538-1 (96906) | AB | EA | 1 | * * * * | 80 | 1 |
| PAOZZ | 4730-301-7470 | COUPLING,PIPE:PRESSURE SENDING UNIT 444000 (24617) | AB | EA | 1 | * * * * | 80 | 2 |
| PAOZZ | 4730-542-5599 | ELBOW,PIPE:OIL PRESSURE SENDING UNIT 44055 (21450) | AB | EA | 1 | * * * * | 80 | 3 |
| PAOZZ | 6685-814-5271 | TRANSMITTER,TEMPERATURE:WATER MS24537-1 (96906) | AB | EA | 1 | * * * * | 80 | 4 |
| PAOZZ | 6685-814-5271 | TRANSMITTER,TEMPERATURE:NEAR WATER OUTLET MANIFOLD MS24537-1 (96906) | AC | EA | 1 | * * * * | 81 | 1 |
| PAOZZ | 6620-814-4770 | TRANSMITTER,OIL PRESSURE:OIL COOLER OUTLET TUBE TO BASE PLATE MS24538-1 (96906) | AC | EA | 1 | * * * * | 81 | 2 |
| 0611-HORN | | | | | | | | |
| PAOZZ | 2590-612-2181 | COVER,HORN BUTTON:(ALSO AVAILABLE IN HORN BUTTON PARTS KIT,FSN 2590-606-8504) 7351271 (19207) | A | EA | 1 | * * * * | 82 | 1 |
| PAOZZ | 2590-384-0570 | BUTTON,HORN CONTACT:(ALSO AVAILABLE IN HORN BUTTON PARTS KIT,FSN 2590-606-8504) 6184126 (19207) | A | EA | 1 | * * * * | 82 | 2 |

AT 22782



Current part is item (4) on diagram. Available at www.oshkoshequip.com




Figure 80. Sending units—multifuel.



Current part is item (4) on diagram. Available at www.oshkoshequip.com