Current part is item (3) on diagram. Available at www.oshkoshequipment.com

(1) SMR Code	(2) Federal Stock Number	(3) Description Reference number & mfg. code	(4) Unit of Meas. Usable on code	(5) Qty Inc In Unit	(6) 15-day organizational Maintenance alw (a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	(7) Illustration (a) Figure No.	(b) Item No.
		0609-LIGHTS-CONTINUED								
PAOZZ	6220-500-3185	LENS,LIGHT:110V WHITE 8328122 (19207)	CE,CF CG EA	1	*	*	*	*	77	2
PAOZZ	6220-025-3697	LENS,LIGHT:110V BLUE 89985 (19975)	CE,CF CG EA	1	*	*	*	*	77	2
PAOZZ	6240-269-0958	LAMP,INCANDESCENT:WHITE 75A115V (08108)	CE,CF CG EA	1	*	*	*	*	77	3
PAOZZ	6240-143-3059	LAMP,INCANDESCENT:BLUE BLACKOUT MS15586-5 (96906)	CE,CF EA	1	*	*	*	*	77	3
		NONILLUSTRATED								
PAOZZ	6220-832-7131	GASKET:COLLECTOR,USED WITH COLLECTOR FLOODLIGHT 8327131 (19207)	HA,JA,BD EA	1	*	*	*	*		
PAOZZ	6220-999-7805	LIGHT,WARNING,AMBER: 8747985-1 (19207)	HA,JA,BD FJ,EF EA	1	*	*	*	*		
PAOZZ	6240-999-7806	LAMP-UNIT,AMBER:WARNING SIGNAL LIGHT 10944453-1 (19207)	A EA	1	*	*	*	*		
PAOZZ	6250-741-8960	LAMPHOLDER AND CLAMP:INSPECTION LIGHT 7408960 (19207)	HA,JA,BD FJ,EF EA	1	*	*	*	*		
		0610-SENDING UNITS AND WARNING SWITCHES NOTE ELECTRICAL TOOL KIT,FSN 5180-876-9336,AUTHORIZED BY TOE WILL BE UTILIZED FOR APPLICABLE REPLACEMENT PARTS NOT SPECIFIED IN THIS GROUP.								
PAOZZ	5305-088-9044	CREW,MACHINE:FUEL TANK TRANSMITTER (5 ,ONLY USED ON M39,M40,M41,M54,M55,M63,M139,M139C,M139D M246) MS35207-260 (96906)	DA,DB,EA EB,EC,HA, BD EA	10	*	*	*	*	78	1
PAOZZ	5310-753-9073	WASHER:SPECIAL VENT COVER SCREW,COPPER,FUEL TANK TRANSMITTER (5 ONLY USED ON M39, M40,M41,M54,M55, M63, M139, M139C,M139D ,M246) 7539073 (19207)	DA,DB,EA EB,EC,HA, BD EA	10	*	*	*	*	78	2
PAOZZ	6680-515-3458	TRANSMITTER,LIQUID QUANTITY:FUEL TANK (1 ONLY USED ON M39, M40, M41, M54, M55, M63, M139, M139C, M139D, M246) 1517596 (70040)	DA,DB,EA EB,EC,HA, BD EA	2	*	*	*	*	78	3
PAOZZ	6680-226-4574	TRANSMITTER,LIQUID QUANTITY:FUEL TANK 8376491 (19207)	CC,CD,DE, DF,FE,FG FH,EG,FJ EA	1	*	*	*	*	78	3

Current part is item (3) on diagram. Available at www.oshkoshequipment.com

Current part is item (3) on diagram. Available at www.oshkoshequipr



Figure 78. Fuel quanity transmitter.

Current part is item (3) on diagram. Available at www.oshkoshequipr