


Current part is item (20) on diagram. Available at [www.oshkoshequipment.com](http://www.oshkoshequipment.com)  
TM5-6115-585-24P  
NAVFAC P-8-623-24P  
TO-35C2-3-455-4  
SL-4-05684C/06585B



TS 6115-585-24P/21

FIGURE 21. Fuel pump assembly—exploded view

Current part is item (20) on diagram. Available at [www.oshkoshequipment.com](http://www.oshkoshequipment.com)

