Current part is item (25) on diagram. Available at www.oshkoshequipment.com



FIGURE 19. EQUALIZING BEAMS, AXLE CENTERING GUIDE, AND RELATED PARTS (AXLES 7 AND 8).

Current part is item (25) on diagram. Available at www.oshkoshequipment.com

Current part is item (25) on diagram. Available at www.oshkoshequipment.com

(1) ITEM NO	(2) SMR CODE	(3) CAGEC	(4) PART NUMBER	(5) DESCRIPTION AND USABLE ON CODES (UOC)	(6) QTY
				GROUP 1108 WALKING BEAMS, STUB AXLES, AND PARTS	
				FIG. 19 EQUALIZING BEAMS, AXLE CENTERING GUIDE, AND RELATED PARTS (AXLES 7 AND 8)	
1	PAFZZ	96906	MS24665-628	PIN, COTTER	4
2	PAFZZ	96906	MS35692-110	NUT,SLOTTED	4
3	PAFZZ	19207	CPR102349	WASHER,FLAT AXLE CENTERING SLEEVE (2) EQUALIZER BEAM SHAFT (2)	4
4	XDFZZ	96906	MS16625-3475	RING,RETAINING AXLE CENTERING SLEEVE TO EQUALIZER BEAM SHAFT, USED ON VEHICLE SERIAL NUMBER 1 THRU 200	1
5	PAFZZ	19207	CPR103846	BUSHING,SLEEVE CENTERING	2
6	PAFZZ	19207	CPR103847	SPACER,PLATE EQUALIZING BEAMS,AXLE CENTERING GUIDE	2
7	PAFZZ	21450	444192	ELBOW,PIPE EQUALIZING BEAMS, AXLE CENTERING GUIDE AND RELATED PARTS	2
8	PAFZZ	96906	MS15003-1	FITTING,LUBRICATION SNATCH BLOCK	4
9	PAFZZ	19207	192032	NIPPLE,LUBE FITTING	2
10	PAFHH	98500	CPR104201	AXLE,VEHICULAR,NOND USED ON VEHICLE SERIAL NUMBER 1 THROUGH 200	2
10	PAFHH	19207	12253821	AXLE USED ON VEHICLE SERIAL NUMBER 201 AND SUBSEQUENT	2
11	PAFZZ	19207	CPR103899	PIN,SHOCK ABSORBER MOUNT	2
12	PAFZZ	19207	CPR102345	PLATE,WEAR,LEAF	4
13	P•AFZZ	98171	AR354	.PIN,STR,HEADLESS	1
14	XDFZZ	19207	CPR102355	WASHER SQUARE	16
15	PAFZZ	96906	MS35338-55	WASHER,LOCK EQUALIZING BEAM ASSEMBLY TO AXLE ASSY	16
16	PAFZZ	96906	MS90727-273	SCREW,CAP,HEX HD	16
17	PAFZZ	98171	AR399	BEAM ASSEMBLY,EQUAL TRAILER AIR SUSPENSION AXLES	2
18	PAFZZ	19207	CPR102351	TORSION BAR,SUSPENS	1
19	PAFZZ	96906	MS20066-537	KEY,MACHINE AXLE BEARING CAP	4
20	PAFZZ	96906	MS24665-360	PIN, COTTER	4
21	PAFZZ	96906	MS35692-72	NUT, SLOTTED	4
22	PAFZZ	19207	10910174-10	WASHER FLAT	4
23	PAFZZ	19207	CPR102335	CAP,PILLOW BLOCK EQUALIZING BEAM TO TRAILER CHASSIS	2
24	PAFZZ	19207	CPR102343	SPACER,RING FOR BUSHING,BEARING, EQUALIZING BEAM TO FRAME BRACKET ASSEMBLY,USED ON VEHICLE SERIAL NUMBER 1 THRU 200	4
24	PAFZZ	19207	CPR102343-1	SPACER,RING FOR BUSHING,BEARING, EQUILIZING BEAM TO FRAME BRACKET ASSEMBLY,USED ON VEHICLE SERIAL NUMBER 201 AND SUBSEQUENT	4
25	PAFZZ	60380	30SF48	BEARING,PLAIN,SELF- USED ON VEHICLE SERIAL NUMBER 201 AND SUBSEQUENT	2

Current part is item (25) on diagram. Available at www.oshkoshequipment.com