


(1) SMR Code	(2) Federal Stock Number	(3) Description	(4) Unit Meas.	(5) Qty	(6) 15-day Maintenance In	(7) Organizational allowance Illustration	(a) Figure No.	(b) Item No.	
		Reference number & mfg. code		Usable on code	(a) 1-5	(b) 6-20	(c) 21-50	(d) 51-100	
		0312-ACCELERATOR AND THROTTLE CONTROLS-CONTINUED							
XAOZZ		SHAFT: THROTTLE CROSS SHAFT 10883234 (19207)			1			36	11
PAOZZ	2590-752-9235	LEVER, REMOTE CONTROL: RIGHT CROSS SHAFT 7529235 (19207)	EA	1	*	*	*	*	36 12
PAOZZ	5310-950-0039	NUT, SELF-LOCKING: CROSS SHAFT CLAMP (1) ACCELERATOR PEDAL STOP (1), CROSS SHAFT CLIP (1) MS210441-N6 (96906)	EA	3	*	*	*	*	36 13
PAOZZ	5340-597-7932	BRACKET: CROSS SHAFT 120520 (24617)	EA	1	*	*	*	*	36 14
PAOZZ	5305-269-2803	SCREW,CAP,HEXAGON HEAD: 3/8-24UNF-2A X 1 IN., CROSS SHAFT BRACKET CLAMP MS90726-60 (96906)	EA	2	*	*	*	*	36 15
PAOZZ	5340-740-9266	CLIP,THROTTLE CONTROL: 7409266 (19207)	EA	1	*	*	*	*	36 16
PAOZZ	5360-753-9129	SPRING,HELICAL,EXTENSION: ANTI-DIESELING VALVE CONTROL (USED WITH CARBURETO, FSN 2910-737-5469 AND CARBURETOR, FSN 2910-832-7282) 7539129 (19207)	EA	1	*	*	*	*	36 17
PAOZZ	2910-699-8476	SPRING,HELICAL,COMPRESSION: RETURN, ANTI- DIESELING VALVE CONTROL (USED WITH CARBURETOR, FSN 2910-562- 0441) 8332670 (19207)	EA	1	*	*	*	*	36 17
PAOZZ		CLIP: CROSS SHAFT 7373265 (19207)	EA	1	*	*	*	*	36 18
PAOZZ	5310-627-6128	WASHER,LOCK: CROSS SHAFT CLIP MS35335-35 (96906)	EA	2	*	*	*	*	36 19
XBOZZ		ROD: LEVER BALL JOINTS 10883236 (19207)	EA	1					36 20
PAOZZ	5315-839-2325	PIN,COTTER: ACCELERATOR PEDAL LEVER MS24665-132 (96906)	EA	2	*	*	*	*	36 21
PAOZZ	5310-080-6004	WASHER,FLAT:.406 ID, ACCELERATOR PEDAL LEVER AND STRAP MS27183-14 (96906)	EA	4	*	*	*	*	36 22
PAOZZ	2590-753-9135	BELL CRANK: PEDAL CONNECTING LINK TO CROSS SHAFT JOINT 1539135 (19207)	EA	1	*	*	*	*	36 23
PAOZZ	2540-115-2565	PEDAL ASSEMBLY CONTROL: 7397798 (19207)	EA	1	*	*	*	*	36 24
PAOZZ	2540-753-9114	PEDAK,CONTROL: ACCELERATOR 7539114 (19207)	EA	1	*	*	*	*	36 25



Current part is item (17) on diagram. Available at www.oshkoshequip.com

AT 47151

Figure 36. Throttle linkage.

Current part is item (17) on diagram. Available at www.oshkoshequip.com