


Figure 194. Air Spring Assembly

Current part is item (5) on diagram. Available at www.oshkoshequipment.com

Section II. REPAIR PARTS LIST

(1) ILLUSTRATION		(2)	(3)	(4)	(6)		(7)	(8)
(a) FIG NO.	(b) ITEM NO.	SMR CODE	NATIONAL STOCK NUMBER	CAGE	PART NUMBER	DESCRIPTION USABLE ON CODE	UM	QTY INC IN UNIT
						GROUP 1601 AIR SPRING ASSEMBLY		
194	1	PAOZZ	2510-01-345-1642	0F5L2	A-10284	BOLT ASSY,AIR SPRG	EA	6
194	2	XAOZZ	- - -	0F5L2	SA-1300-4	.NUT,HEX 1/2-13	EA	2
194	3	XAOZZ	- - -	0F5L2	SA-1600-4	.WASHER,LOCK 1/2	EA	4
194	4	XAOZZ	- - -	0F5L2	SA-1000-3	.SCREW,CAP 1/2-13 X 1 1/4	EA	2
194	5	PAOZZ	2510-01-337-4119	0F5L2	C-10443	SPRING,AIR,REAR	EA	6



Current part is item (5) on diagram. Available at www.oshkoshequipment.com