



Figure 96. Transmission Assembly

Section II. REPAIR PARTS LIST

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) DESCRIPTION | (7) | (8) |
|---------------------|--------------------|-------------|-----------------------------|-------|----------------|-------------------------------------|-----|--------------------------|
| (a) FIG NO. | (b) ITEM NO. | SMR CODE | NATIONAL STOCK NUMBER | CAGE | PART NUMBER | USABLE ON CODE | UM | QTY INC IN UNIT |
| | | | | | | GROUP 0710 TRANSMISSION ASSEMBLY | | |
| 96 | 1 | PAFHH | 2520-01-354-6915 | 19207 | 57K3048 | XMSN,W/CONTAINER | EA | 1 |
| 96 | 2 | PAFHH | 2520-01-340-1592 | 19207 | 12436584 | .XMSN ASSY,DRESSED | EA | 1 |
| 96 | 3 | PAFZZ | 2520-01-354-9237 | 72447 | 6,5-4-3361-1 | .YOKE,OUPUT,TRANS | EA | 1 |