



Figure 21. Coolant Temperature, Oil Pressure, and Fuel Level Transmitters

AIR FORCE T.O. 35C2-3-442-14  
 ARMY TMS-6115-600-24P  
 NAVY NAVFAC P-8-628-24P  
 MARINE CORPS S-L4-07464B

SECTION II. REPAIR PARTS FOR ORGANIZATIONAL, INTERMEDIATE (FIELD)  
 (DIRECT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		(4)	(5) DESCRIPTION	(6)	(7) QTY INC IN UNIT	(8) USMC QTY PER EQUIP
a	b	a	b	c	d	a	b	NATIONAL STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	U/M	
FIG NO.	ITEM NO.	ARMY	AIR FORCE	NAVY	USMC	SSI	REPL FACTOR					
21									GROUP 03 - SET CONTROLS AND INSTRUMENTATION			
21	1	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.030	6685-00-119-9852	COOLANT TEMPERATURE, OIL PRESSURE, AND FUEL LEVEL TRANSMITTERS			
									TEMPERATURE TRANSMITTER, MT2	EA	1	1
									69-781 30554 506-AE 57733			
21	2	PAOZZ	PAOZZ	PAOZZ	PAFZZ		.050	6620-00-134-1593	OIL PRESSURE TRANSMITTER, MT1	EA	1	1
									69-779-2 30554 506-AD 57733			
21	3	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.008	6680-00-676-9242	FUEL LEVEL TRANSMITTER, MT3	EA	1	1
									MS500040-2 81348			
21	4	PAOZZ	PAOZZ	PAFZZ	PAFZZ			4730-00-277-5609	BUSHING, ADAPTER	EA	1	1
									AN912-7 88044			

