



TA215445

FIGURE 77. TOP INPUT AND OUTPUT SHAFT (MODELS M916, M917, M918, M919 AND M920).

SECTION II (1)	II (2)	(3)	TM9-2320-273-24P (4)	(5)	(6)
ITEM NO	SMR CODE	FSCM	PART NUMBER	DESCRIPTION AND USABLE ON CODE (UOC)	QTY
GROUP:08 TRANSFER AND FINAL DRIVE ASSEMBLIES					
GROUP:0801 POWER TRANSFER AND FINAL DRIVE ASSEMBLIES					
FIGURE 77. TOP INPUT AND OUTPUT SHAFT (MODELS M916, M917, M918, M919 AND M920).					
1	PAFFH	45152	118008RU	TRANSFER TRANSMISSI UOC:U22,U23,U24,U25,U26	1
2	PAFZZ	45152	25806A	.LOCKWIRE V UOC:U22,U23,U24,U25,U26	
3	PAOZZ	45152	738-H-1	.SCREW,CAP,HEXAGON UOC:U22,U26	2
3	PAFZZ	45152	400A2	.SCREW,CAP,HEXAGON UOC:U23,U24,U25	6
4	PAFZZ	45152	21745F	.SPACER,PLATE UOC:U22,U23,U24,U25,U26	2
5	PAFZZ	78500	92NYS40-34	.YOKE,UNIVERSAL JOIN UOC:U22,U23,U24,U25,U26	2
6	PAFZZ	01212	417352	.SEAL,OIL UOC:U22,U23,U24,U25,U26	1
7	PAFZZ	45152	104555D	.PLATE,RETAINING UOC:U22,U23,U24,U25,U26	1
8	PAFZZ	45152	18108F	.GASKET PART OF KIT P/N 2SK-353 UOC:U22,U23,U24,U25,U26	2
9	PAFZZ	45152	18151F	.BEARING,BALL,ANNULA UOC:U22,U23,U24,U25,U26	2
10	PAFZZ	45152	18020-F	.GEAR,HELICAL UOC:U22,U23,U24,U25,U26	1
11	PAOZZ	45152	352-AX	.WASHER,LOCK UOC:U22,U23,U24,U25,U26	16
12	PBFZZ	45152	376A1	.NUT,PLAIN,HEXAGON UOC:U22,U23,U24,U25,U26	16
13	XAFZZ	45152	68954R	.HOUSING UOC:U22,U23,U24,U25,U26	1
14	PAFZZ	45152	18107F	.KEY,MACHINE UOC:U22,U23,U24,U25,U26	2
15	PBFZZ	45152	117992-A	.SPIRAL PIN UOC:U22,U26	1
16	PFFZZ	45152	19817FX	.TANG,DRIVE,PUMP TRA UOC:U23,U24,U25	1
16	PAFZZ	45152	115244-C	.TANG,DRIVE,PUMP TRA UOC:U22,U26	1
17	PAFZZ	45152	13331F	.SPACER,RING UOC:U22,U23,U24,U25,U26	1
18	PAFZZ	21760	1218	.BEARING,BALL,ANNULA UOC:U22,U23,U24,U25,U26	1
19	PAFZZ	45152	68692D	.SHAFT,SHOULDERED UOC:U22,U23,U24,U25,U26	1
20	PBFZZ	45152	53427-A	.STUD,PLAIN	16