



TA215417

FIGURE 47. SENDING UNITS AND WARNING SWITCHES.

Current part is item (5) on diagram. Available at [www.oshkoshequipment.com](http://www.oshkoshequipment.com)

SECTION II (1)	ITEM (2)	SMR (3)	FSCM (4)	PART (5)	DESCRIPTION AND USABLE ON CODE (UOC) (6)	QTY
					GROUP:0610 SENDING UNITS AND WARNING SWITCHES	
					FIGURE 47. SENDING UNITS AND WARNING SWITCHES.	
1	PAOZZ	57733	334AD		TRANSMITTER, PRESSUR	1
2	PAOZZ	70040	6402609		SWITCH, PRESSURE	1
3	PAOZZ	89346	416372C1		SWITCH, SENSITIVE	1
					UOC: U22, U23, U24, U25, U26	
4	PAOZZ	11083	9G8010		SWITCH, PRESSURE ENGINE RETARDER	1
5	PAOZZ	57733	334-S		SENSOR, TEMPERATURE	1
6	PAOZZ	09527	2901-21		SWITCH, PRESSURE LOW ENGINE OIL	1
					PRESSURE	
7	PAOZZ	96906	MS35650-302		NUT, PLAIN, HEXAGON	1
8	PAOZZ	34623	5962514		WASHER, LOCK	1
9	PAOZZ	95879	353-BY		SWITCH, PRESSURE OIL PRESSURE, ENGINE	1
10	PAOZZ	34623	MB242A-20153		LEVER, MANUAL CONTRO	1
					UOC: U22, U23, U24, U25, U26	
11	PAOZZ	34623	MB10-20112		BRACKET, MOUNTING	1
					UOC: U22, U23, U24, U25, U26	
12	PAOZZ	13445	90043-18		SWITCH, PUSH	1
					UOC: U22, U23, U24, U25, U26	
13	PAOZZ	96906	MS45904-76		WASHER, LOCK	1
					UOC: U22, U23, U24, U25, U26	
14	PAOZZ	75272	COV-0517Z1		STRAP, RETAINING	1
					UOC: U22, U23, U24, U25, U26	
15	PAOZZ	24617	273228		SCREW, ASSEMBLED	2
16	PAOZZ	06853	280337		SWITCH, PUSH	1
17	PAOZZ	09527	2904-106		SWITCH, PRESSURE DIFFERENTIAL	1
					LOCKOUT	
18	PAOZZ	09527	2902		SWITCH, PRESSURE PARKING BRAKE	1
19	PAOZZ	57733	391-JK		TRANSMITTER, LIQUID	1
					END OF FIGURE	

Current part is item (5) on diagram. Available at [www.oshkoshequipment.com](http://www.oshkoshequipment.com)