Current part is item (6,8,4) on diagram. Available at www.oshkoshequipment.com Section II. IM 9-2320-272-34P-1




Figure 154. Propeller Shaft Assembly, Front Axle to Transfer Shaft.

Current part is item (6,8,4) on diagram. Available at www.oshkoshequipment.com Section II. IM 9-2320-272-34P-1





Figure 155. Propeller Shaft Assembly, Transfer to Front Axle Shaft.

Current part is item (6,8,4) on diagram. Available at www.oshkoshequipment.com Section II. IM 9-2320-272-34P-1



TA 467892

Figure 158. Propeller Shaft Assembly, Forward Rear Axle to Rear Rear Axle.