

SECTION II. REPAIR PARTS FOR ORGANIZATIONAL, INTERMEDIATE (FIELD)
 (DIRECT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE

(1) ILLUS- TRATION		(2) SMR CODE				(3) USMC		(4)	(5) DESCRIPTION		(6)	(7)	(8)
a	b	a	b	c	d	a	b	NATIONAL STOCK NUMBER	REF NUMBER & MFR CODE	USABLE ON CODE	U/M	QTY INC IN UNIT	USMC QTY PER EQUIP
FIG NO.	ITEM NO.	ARMY	AIR FORCE	NAVY	USMC	SSI	REPL FACTOR						
19									GROUP 03 - SET CONTROLS AND INSTRUMENTATION				
19	1	PAOZZ	PAOZZ	PAFZZ	PAFZZ	D	.008	5305-00-068-0501	CONTROL CUBICLE ASSEMBLY				
19	2	PAOZZ	PAOZZ	PAFZZ	PAFZZ	D	.010	5310-00-582-5965	SCREW, HEX HEAD MS90725-5	96906	EA	11	114
19	3	PAOZZ	PAOZZ	PAFZZ	PAFZZ	D	.008	5305-00-225-3839	WASHER, LOCK MS35338-44	96906	EA	14	154
19	4	AOO	AOO	AOO	AOO				SCREW, HEX HEAD MS90725-8	96906	EA	3	35
19	5	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.050	6625-00-004-8066	CONTROL CUBICLE 69-390-6	30554	EA	1	1
19	6	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.050	6625-00-869-3144	METER CURRENT, M8 69-597 257842	30554 65092	EA	1	1
19	7	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.050	6625-00-869-3144	METER, VOLTAGE, M9 69-599 254013	30554 65092	EA	1	1
19	8	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.050	6625-00-003-0975	METER, KILOWATT, M7 70-4012 280933	30554 65092	EA	1	1
19	9	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.05	6625-00-003-0971	METER, FREQUENCY, AND TRANSDUCER, MATCHED SET M6 AND A2 69-595 268420	30554 65092	EA	1	1
19	10	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.060	5930-00-214-0431	SWITCH VOLT - AMPXFR, S8 70-4016 3194LT	30554 82121	EA	1	1
19	11	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.050	6685-00-857-0662	INDICATOR, TEMPERATURE, M2 69-577 505-BE	30554 57733	EA	1	1
19	12	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.060	6620-00-005-4879	INDICATOR, OIL PRESSURE, M1 69-576-2 505-BD	30554 57733	EA	1	1
19	13	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.050	6680-00-052-3544	INDICATOR, LIQUID QUANTITY M3 69-575 505-BC	30554 57733	EA	1	1
19	14	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.060	6625-00-869-3141	AMMETER, DC, M4 69-574 252633	30554 65092	EA	1	1
19	15	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.050	6645-00-089-8842	METER, TIME TOTAL, MS 730507 15001	30554 74400	EA	1	1
19	16	PAOZZ	PAOZZ	PAFZZ	PAFZZ	D	.040	6810-00-935-6919	LIGHT, PANEL, DS1, DS2, DS3 69-593 47-0901-2800-201	30554 72819	EA	3	3
19	17	PAOZZ	PAOZZ	PAOZZ	PAOZZ		.230	6240-00-155-7878	LAMP, INCANDESCENT 69-594 656-30V	30554 08805	EA	3	3
19	18	PAOZZ	PAOZZ	PAFZZ	PAFZZ	D	.050	5355-00-916-2060	KNOB, CONTROL MS91528-2P4B	96906	EA	1	1
19	19	PAOZZ	PAOZZ	PAFZZ	PAFZZ		.050	5905-00-264-7368	RHEOSTAT, R2 69-548 RP101FD251KK	30554 44655	EA	1	1
19	19	PAOZZ	PAOZZ	PAOZZ	PAOZZ		.040	6210-00-686-4999	LIGHT ASSY, DS6, DS7 MS29831-2	96906	EA	2	2

AIR FORCE T.O. 35C2-3-442-14
ARMY TM5-6115-600-24P
NAVY NAVFAC P-8-628-24P
MARINE CORPS SL-4-07464B




Figure 19. Control Cubicle Assembly (Sheet 2 of 3)