Current part is item (1) on diagram. Available at www.oshkoshequipment.com

| (1) SMR CODE | (2) FEDERAL STOCK NUMBER | (3) DESCRIPTION / REFERENCE NUMBER & MFR CODE | USABLE ON CODE | (4) UNIT OF MEAS | (5) QTY INC IN UNIT | (6) 15-DAY ORGANIZATION MAINTENANCE ALLOWANCE (A) 1-5 | (B) 6-20 | (C) 21-50 | (D) 51-100 | (7) 30-DAY DS MAINTENANCE ALLOWANCE (A) 1-20 | (B) 21-50 | (C) 51-100 | (8) 30-DAY GS MAINTENANCE ALLOWANCE (A) 1-20 | (B) 21-50 | (C) 51-100 | (9) 1-YR. ALW PER 100 EQUIP CNTGCY PLANNING | (10) ILLUSTRATION (A) FIG NO | (B) ITEM NO |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| XAOZZ | | CLIP,SPRING: SMALL<br>7979422(19207) | | EA | 4 | | | | | | | | | | | | 36 | 7 |
| XAOZZ | | RIVET,SOLID: 3/8X 15 16<br>110952 (21450) | | EA | 16 | | | | | | | | | | | | 36 | 8 |
| XAOZZ | | LEAF,SPRING: 37 1/2 IN<br>7979414 (19207) | | EA | 2 | | | | | | | | | | | | 36 | 9 |
| XAOZZ | | LEAF,SPRING: 33 1/2 IN.<br>7979415 (19207) | | EA | 2 | | | | | | | | | | | | 36 | 10 |
| XAOZZ | | LEAF,SPRING: 30 IN.<br>7979416 (19207) | | EA | 2 | | | | | | | | | | | | 36 | 11 |
| PAOZZ | 5310-891-1711 | NUT,PLAIN,HEX: 7 16-14UNC-2B (LARGE CLIP)<br>MS35691-25(96906) | | EA | 4 | * | * | * | * | * | * | * | * | * | * | | 36 | 12 |
| PAOZZ | 5305-042-9477 | BOLT,HEX HD: 7 16-14UNC-2A (LARGE CLIP)<br>MS90725-9) (96996) | | EA | 4 | * | * | * | * | * | * | * | * | * | * | | 36 | 13 |
| XAOZZ | | CLIP,SPRING: LARGE<br>7979421 (19207) | | EA | 4 | | | | | | | | | | | | 36 | 14 |
| XAOZZ | | LEAF,SPRING: 26 1/2 IN.<br>7979417 (19207)<br>7979417 (19207) | | EA | 2 | | | | | | | | | | | | 36 | 15 |
| XAOZZ | | LEAF,SPRING: 22 1/2 IN.<br>7979418 (19207) | | EA | 2 | | | | | | | | | | | | 36 | 16 |
| XAOZZ | | LEAF,SPRING: 18 1/4 IN.<br>7979419 (19207) | | EA | 2 | | | | | | | | | | | | 36 | 17 |
| PAOZZ | 5306-206-7279 | BOLT,MACH:SPRING CENTER BOLT<br>7979425 (19207) | | EA | 2 | * | * | * | * | * | * | * | * | * | * | | 36 | 18 |
| XAOZZ | | LEAF,SPRING: 15 1/4 IN.<br>7979420 (19207) | | EA | 2 | | | | | | | | | | | | 36 | 19 |
| PAOZZ | 5310-010-3028 | NUT,PLAIN,HEX: 1/2-20UNF-2B<br>103028 (21450) | | EA | 2 | * | * | * | * | * | * | * | * | * | * | | 36 | 20 |
| XAOZZ | | SPACER:SPRING LARGE CLIP<br>7979423 (19207) | | EA | 4 | | | | | | | | | | | | 36 | 21 |
| | | 1605-TORQUE RODS AND BRACKETS | A | | | | | | | | | | | | | | | |
| PAOFZ | 2530-797-9189 | TORQUE ROD ASSY: W ENDS<br>7979189 (19207)<br>COMPOSED OF:<br>2 END. 7979185 (19207)<br>2 NUT. 175079 (21450)<br>1 ROD. 7979188 (19207) | | EA | 6 | * | * | * | * | * | * | * | * | * | * | | 37 | 1 |
| XAFZZ | | ROD ASSY: W BALL ENDS (WELDED)<br>7979188 (19207) | | EA | 6 | | | | | | | | | | | | 37 | 2 |
| PAFZZ | 2530-740-9620 | BALL ASSY: W STUD & BRG. SWAGED<br>7409620 (19207) | | EA | 12 | | | | | * | * | * | * | * | * | | 37 | 3 |



Current part is item (1) on diagram. Available at www.oshkoshequipment.com



Current part is item (1) on diagram. Available at www.oshkoshequi

*Figure 36. Spring assembly (7979217)—assembled view.*




*Figure 37. Torque rods, spring guide brackets, and attaching parts—exploded view.*

Current part is item (1) on diagram. Available at www.oshkoshequi