Current part is item (69) on diagram. Available at www.oshkoshequipment.com







Figure 24. Control Cubicle Assembly (Sheet 2 of 2)



Current part is item (69) on diagram. Available at www.oshkoshequipment.com

Current part is item (69) on diagram. Available at www.oshkoshequipment.com



| (1) ILLUSTRATION | | (2) SMR CODE | | | | (3) USMC | | (4) | (5) DESCRIPTION | | | (6) | (7) | (8) |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| (a) FIG NO. | (b) ITEM NO. | a ARMY | b AIR FORCE | c NAVY | d USMC | a SSI | b REPL FACTOR | NATIONAL STOCK NUMBER | REF NUMBER | MFR CODE | USABLE ON CODE | U/M | QTY INC IN UNIT | USMC QTY PER EQUIP |
| | | | | | | | | | GROUP 05 - CONTROL CUBICLE (CONTINUED) | | | | | |
| 24 | 65 | PAFZZ | PAFZZ | PAFZZ | | | | 5935-01-046-4355 | SOCKET, RELAY, 24 VDC | | | EA | 1 | |
| | | | | | | | | | 76-11303 | 30554 | | | | |
| | | | | | | | | | 33377 | 78290 | | | | |
| 24 | 66 | PAFZZ | PAFZZ | PAFZZ | | | | 5305-00-036-6977 | SCREW AND CAPTIVE WASHER ASSY | | | EA | 4 | |
| | | | | | | | | | 69-662-33 | 30559 | | | | |
| | | | | | | | | | P-15121-33 | 45722 | | | | |
| 24 | 67 | PBFZZ | PBFZZ | PBFZZ | | | | 5945-01-070-7562 | RELAY, REVERSE POWER | | | EA | 1 | |
| | | | | | | | | | 76-11240 | 30554 | | | | |
| | | | | | | | | | RP150 | 57647 | | | | |
| 24 | 68 | PAFZZ | PAFZZ | PAFZZ | | | | 5305-00-038-3103 | SCREW AND CAPTIVE WASHER ASSY | | | EA | 4 | |
| | | | | | | | | | 69-662-35 | 30554 | | | | |
| | | | | | | | | | P-15121-35 | 45722 | | | | |
| 24 | 69 | PAFZZ | PAFZZ | PAFZZ | | | | 5945-00-057-5655 | RELAY, OVERVOLTAGE | | | EA | 1 | |
| | | | | | | | | | 70-1138 | 30554 | | | | |
| | | | | | | | | | 4453 | 13483 | | | | |
| 24 | 70 | PAFZZ | PAFZZ | PAFZZ | | | | 5305-00-038-3103 | SCREW AND CAPTIVE WASHER ASSY | | | EA | 4 | |
| | | | | | | | | | 69-662-35 | 30554 | | | | |
| | | | | | | | | | P-15121-35 | 45722 | | | | |
| 24 | 71 | PAFZZ | PAFZZ | PAFZZ | | | | 5945-00-192-0245 | MODULE, RELAY, SHORT CIRCUIT | | | EA | 1 | |
| | | | | | | | | | 70-1137 | 30554 | | | | |
| | | | | | | | | | 800 | 25248 | | | | |
| 24 | 72 | PAFZZ | PAFZZ | PAFZZ | | | | 5305-00-036-6977 | SCREW AND CAPTIVE WASHER ASSY | | | EA | 4 | |
| | | | | | | | | | 69-662-33 | 30554 | | | | |
| | | | | | | | | | P-15121-33 | 45722 | | | | |
| 24 | 73 | XBFZZ | XBFZZ | XBFZZ | | | | | BRACKET, SUPPORT | | | EA | 2 | |
| | | | | | | | | | 76-11331-2 | 30554 | | | | |
| 24 | 74 | | | | | | | 5305-00-036-6977 | SCREW AND CAPTIVE WASHER ASSY | | | EA | 6 | |
| | | | | | | | | | 69-662-33 | 30554 | | | | |
| | | | | | | | | | P-15121-33 | 45722 | | | | |
| 24 | 75 | PAFZZ | PAFZZ | PAFZZ | | | | | NUT AND CAPTIVE WASHER ASSY | | | EA | 6 | |
| | | | | | | | | | 69-561-3 | 30554 | | | | |
| | | | | | | | | | 511-081800-00 | 78189 | | | | |
| 24 | 76 | PAFFH | PAFFH | PAFFH | | | | 6350-01-073-3408 | ANNUNCIATOR CONTROL ASSY (SEE FIGURE 30 FOR BREAKDOWN) | | | EA | 1 | |
| | | | | | | | | | 76-11272 | 30554 | | | | |
| 24 | 77 | PAFZZ | PAFZZ | PAFZZ | | | | 5305-00-03B-5103 | SCREW CAP ASSY | | | EA | 4 | |
| | | | | | | | | | 69-662-35 | 30554 | | | | |
| | | | | | | | | | P-15121-35 | 45722 | | | | |
| 24 | 78 | PAFZZ | PAFZZ | PAFZZ | | | | 5945-00-204-6546 | MODULE, RELAY, UNDERVOLTAGE | | | EA | 1 | |
| | | | | | | | | | 70-1120 | 30554 | | | | |
| | | | | | | | | | 4456 | 12670 | A | | | |
| | | | | | | | | | 1456 | 13483 | B | | | |



Current part is item (69) on diagram. Available at www.oshkoshequipment.com